



UK Sampling Gauges Ltd

Building 1, Roman Bank, Bourne, Lincolnshire, PE10 9LQ, UK

Tel: +44 (0)1778 392818 Fax: +44 (0)1778 421169

E-mail: sales@samplinggauges.com

Web site: www.samplinggauges.com



Any-level, Self-sealing Sampler ALSC 1002

Applications

These samplers will take truly representative liquid samples from any level within a tank or reservoir.

The samplers stay empty and sealed until they reach the required depth, when the operator opens the top valve by a snatch on the cable. The sampler then fills, re-seals by means of a polypropylene ball, and stays sealed until the operator separates the canister from the valve assembly.

The design of the self-sealing feature minimises the amount of liquid that overflows when the sampler is opened.

Because of the design and method of operating, these samplers take particularly accurate samples, undiluted by the passage of the sampler through the liquid. They are suited to taking samples for quality, density, RVP, and appearance, for example.



ALSC 1002

Specifications

| | |
|------------------|---------------------|
| Overall diameter | 64mm |
| Sampler Capacity | 1 Litre |
| Weight (empty) | 2kg |
| Material | 316 Stainless Steel |

Please contact us if you require further information about these or other equipment offered by **UK Sampling Gauges Ltd**, or if you require equipment to be adapted or modified.